





REGULAR DISPLAY AND BUTTON OPERATION

E-01




HOW TO SET NORMAL TIME

E-02




HOW TO DISPLAY MONTH, DATE

E-04




12/24 HOUR FORMAT DISPLAY




HOW TO SET ALARM TIME

E-06




HOW TO USE ALARM AND CHIME DISPLAY

E-07



HOW TO USE THE CHRONOGRAPH

E-08



FEATURES AND SPECIFICATIONS

E-11

- Standard display mode: Hour, Minutes, Seconds, Day of week.
- Function:
 - * Month, Date AM/PM and Electro-Luminescent light.
 - * Alarm function with buzzer signal output.
 - * Chronograph function with lap operation.
 - * Hourly chime.
 - * 12/24 hour format switch option.
- Accuracy at normal temperature (25°C): ±30 seconds a month.
- Normal operating temperature range: 10°C - 40°C.