



X1113 SWING (MENS)




REGULAR DISPLAY AND BUTTON OPERATION




BUTTON OPERATION

- | | |
|-----------------|-----------------|
| A ADJUST | C ST/STP |
| B MODE | D LIGHT |


HOW TO SET NORMAL TIME




HOW TO SET NORMAL TIME




HOW TO DISPLAY MONTH, DATE



12/24 HOUR FORMAT DISPLAY




HOW TO USE EL LIGHT




NOTE:

1. The backlight of the watch employs an electro-luminescent (EL) light, watch tends to lose illuminating power after very long use.
2. The illumination provided by backlight may be hard to see when viewed under direct sunlight.

HOW TO SET ALARM TIME




HOW TO USE ALARM AND CHIME DISPLAY



HOW TO USE THE CHRONOGRAPH



HOW TO USE THE CHRONOGRAPH



LAP

