



# USER'S GUIDE

YP13523 (MULTIFUNCTION SPORT LCD WATCH)



## BUTTONS


- The operation of buttons are indicated using the letters shown in the illustration.



- A -- Reset
- B -- Mode
- C -- EL Backlight
- D -- Start/ Stop

## DISPLAY

- The screen shown in below:



## ATTENTION

- Never try to open the case or remove its back cover.
- Do not operate buttons underwater.
- Should moisture appear inside the watch, have it checked immediately by your dealer. Otherwise it can cause erosion of the metal parts of the watch.
- Though the watch is designed to withstand normal use, you should avoid rough use or dropping the watch.
- Avoid exposing the watch to temperature extremes.
- Wipe the watch with dry, soft cloth only. Avoid allowing it to come into direct contact with chemical materials, which can cause deterioration of the plastic parts of the watch.
- Avoid to wear the watch in electromagnetic, static conditions.

## MODE SELECTION

- Press "B" to change mode to mode in the following Sequence: Timekeeping Mode - Stopwatch Mode - Alarm Mode - Time Setting Mode.

### A TIMEKEEPING

- Hour, Minutes, Seconds, Day of week.
- Build in Date.

### B STOPWATCH





- 1/100 second unit.
- Measuring range: 0:00:00 - 23:59:59"

### C ALARM

- The alarm sounds at the preset time each day.
- Hourly time signal.
- Snooze for 5 minutes.

### D TIMESETTING

- Hour, Minutes, Seconds, Month, Date, Day of week can be set.




## BACKLIGHT

- The backlight that uses an EL (electroluminescent) cause the display to glow for easy reading in the dark.

### Use EL Backlight

- In any mode, press "C" to illuminate the display about 3 seconds.



## A TIMEKEEPING

### Display The Date






- In the timekeeping mode, press and hold "D" to display the date.

### On/Off The Alarm

- In the timekeeping mode, press and hold "A" display the alarm time.
- Press "D" at the same time to on/off the alarm.

### On/Off The Chime





- In the timekeeping mode, press and hold "A" display the alarm time.
- Press "B" at the same time to on/off the chime.



## C ALARM

### Alarm Time Setting

- In the alarm mode, the hour to flash:



- Press "D" to increase the hour, press and hold to increase at high speed.
- Press "A" to select the minutes.


- Press "D" to increase the minutes, press and hold to increase at high speed.

- Press "B" to return the timekeeping mode, after you set.
- Press "B" to return the timekeeping mode, after you set.
- The alarm sounds at preset time each day for about 60 seconds.
- Press "D" to break it, the alarm continue after 5 minutes.
- Press "A" to stop it.

## B STOPWATCH




### A Lap Time

- In the stopwatch mode, press "D" to start the stopwatch.
- To stop the stopwatch by pressing "D" again.
- Press "A" to reset the stopwatch.



### Split Time

- In the stopwatch mode, press "D" to start the stopwatch.
- Press "A" to display the split time, stopwatch timing continues internally.
- Press "A" to clear the split time and to continue time measurement.
- Repeat step 2 and 3, you can measure the multi split time.
- Press "D" to stop the stopwatch.



## D TIMESETTING

### Time Setting

- In the time setting mode, the seconds to flash.
  - Press "D" to reset the seconds.
  - Press "A" change to the next selection.
  - Press "D" to increase the number, press and hold to increase at high speed.
  - Repeat step 3 and 4, the selection in the following sequence: Seconds - Minutes - Hour - Date - Month - Day of week.
  - Press "B" to return the timekeeping mode, after you set.
- \* 12 / 24H formats can be selected, when hour setting.

