





## HOW TO SET NORMAL TIME

E-02




## HOW TO SET NORMAL TIME

E-03




## HOW TO DISPLAY MONTH, DATE

E-04




## 12/24 HOUR FORMAT DISPLAY



- HOLD "A" PRESS "B" SELECT 12 OR 24 HOUR FORMAT.
- 12 HOUR FORMAT: "12:00:00" IN CASE OF 24 FORMAT, "00:00:00" "A" OR "P" MARK APPEARS.

## HOW TO USE EL LIGHT

E-05




## NOTE:

- The backlight of the watch employs an electro-luminescent (EL) light, watch tends to lose illuminating power after very long use.
- The illumination provided by backlight may be hard to see when viewed under direct sunlight.


## HOW TO SET ALARM TIME

E-06



## HOW TO USE THE CHRONOGRAPH

E-07



## CARE OF YOUR WATCH

E-10

- This watch contains precise electronic components. Never attempt to open the case or remove the back cover.
- Do not operate push buttons below the surface of the water when swimming or diving.
- Should water or condensation appear in the watch, immediately have the watch checked. Water can corrode electronic parts inside the case.
- Avoid severing impact: The watch is designed to withstand impact under normal use. It is inadvisable to subject it to severe impact of rough usage or drops onto hard surfaces.
- Avoid exposing the watch to temperature extremes.
- Clean the watch with a soft cloth and clean water only. Avoid using chemicals, especially soap.
- Keep your watch away from the conditions of strong electric field and static electricity.

GUARANTEE CERTIFICATE  
CERTIFICAT DE GARANTIE

MODEL: \_\_\_\_\_

DATE OF PURCHASE: \_\_\_\_\_

DATE D'ACHAT: \_\_\_\_\_

OFFICE DEALER STAMP:  
TAMPON DU DETAILLANT OFFICIEL:

## FEATURES AND SPECIFICATIONS

E-11

- Standard display mode: Hour, Minutes, Seconds, Month, Day of week.
- Function:
  - Month, Date AM/PM and Electro-Luminescent light.
  - Alarm function with buzzer signal output.
  - Chronograph function with lap operation.
  - Hourly chime.
  - 12/24 hour format switch option.
- Accuracy at normal temperature (25°C): ±30 seconds a month.
- Normal operating temperature range: 10°C - 40°C.